




Assembly Instruction

ITEM NO.: 8449BK/BU/BR/GY-1PWHM


Power Reclining Chair with Power
Headrest, Storage Arms with Cup
Holders, Air Massage and Heat, LED
Lighting and Charging Ports

Note: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


Component list

No	Drawing	Qty	Description
A		1	SEAT
B		1	BACK REST
C		1	ADAPTOR



Step #1



Step #2



Step #3



- 1 **LED light setting:**
Mode 1: 50% brightness
Mode 2 : 75% brightness
Mode 3 : 100% brightness
Mode 4 : OFF
- 2 **USB PORT**
- 3 **USB Type C**
- 4 **3 modes massager:**
Mode 1-Press once to activate continuously high speed rolling.
Mode 2-Press again/twice to activate mid speed rolling with pause.
Mode 3-Press again/three times to active low speed rolling with pause
Press again/4 times to turn off rolling.
- 5 **Heating:**
Press once with one beep to start heating.
Press again/twice with two beeps to increase the heat.
Press again/3rd time with one beep to turn off the heating.
- 6 **Open recliner**
- 7 **Close recliner**
- 8 **Open headrest**
- 9 **Close headrest**
- 10 **Home button / Indicator light button**

Home button: Reset recliner and headrest

**Massage and heating functions automatically turn off without operation after 30 minutes.


Home button / Indicator light button

•Blue Light – Massage function is ON

•Red Light – Heating function is ON

•Blue + Red Lights – Both Massage and Heating are ON at the same time.

•Light OFF – Both Massage and Heating are OFF.



Care Instruction for Genuine Leather match with PVC Furniture:

In order to maintain the original appearance of your Genuine Leather match with PVC, please follow below simple care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and or exposure to heating and air conditioning outlets will fade/damage Genuine Leather match with PVC.
- Vacuum or wipe with a soft cloth to remove dust.
- Hardware may loosen over time. Periodically check to make sure all connection are tight, Re-tighten if necessary.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.